

DXM G2 Series

Digital Xtreme Card Cages 8x8, 16x16, 32x32



SAFETY INSTRUCTIONS

Please review the following safety precautions. If this is the first time using this model, then read this manual before installing or using the product. If the product is not functioning properly, please contact your local dealer or Aurora for further instructions.



The lightning symbol in the triangle is used to alert you to the presence of dangerous voltage inside the product that may be sufficient to constitute a risk of electric shock to anyone opening the case. It is also used to indicate improper installation or handling of the product that could damage the electrical system in the product or in other equipment attached to the product.



The exclamation point in the triangle is used to alert you to important operating and maintenance instructions. Failure to follow these instructions could result in injury to you or damage to the product.



Be careful with electricity:

- **Power outlet:** To prevent electric shock, be sure the electrical plug used on the product power cord matches the electrical outlet used to supply power to the Aurora product. Use only the power adapter and power connection cables designed for this unit.
- **Power cord:** Be sure the power cord is routed so that it will not be stepped on or pinched by heavy items.
- **Lightning:** For protection from lightning or when the product is left unattended for a long period, disconnect it from the power source.



Also follow these precautions:

- **Ventilation:** Do not block the ventilation slots if applicable on the product or place any heavy object on top of it.
Blocking the air flow could cause damage. Arrange components so that air can flow freely. Ensure that there is adequate ventilation if the product is placed in a stand or cabinet. Put the product in a properly ventilated area, away from direct sunlight or any source of heat.
- **Overheating:** Avoid stacking the Aurora product on top of a hot component such as a power amplifier.
- **Risk of Fire:** Do not place unit on top of any easily combustible material, such as carpet or fabric.
- **Proper Connections:** Be sure all cables and equipment are connected to the unit as described in this manual.
- **Object Entry:** To avoid electric shock, never stick anything in the slots on the case or remove the cover.
- **Water Exposure:** To reduce the risk of fire or electric shock, do not expose to rain or moisture.
- **Cleaning:** Do not use liquid or aerosol cleaners to clean this unit. Always unplug the power to the device before cleaning.
- **ESD:** Handle this unit with proper ESD care. Failure to do so can result in failure.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Trademarks

All trademarks in this document are the properties of their respective owners.




TABLE OF CONTENTS

PACKAGE CONTENTS	2
INTRODUCTION.....	3
About.....	3
Features	3
MATRIX FRAMES, CARDS, & ACCESSORIES	4
DESCRIPTION.....	7
Front Panel DXM G2 Series	7
Rear Panel DXM G2 Series	8
OPERATION	9
Front Panel Menu Settings	9
Switching with Front Panel	11
EDID Management	13
CARD FUNCTIONALITY	14
HDBaseT Cards	14
HDMI Cards	15
SERIAL COMMANDS.....	16
RS-232 Commands	16
RS-232 Command Usage.....	19
DXW-2 Series Wall Plate RS-232 Reporting Examples	20
CONNECTOR PIN DEFINITION	21
RS-232 Serial Port.....	21
HDMI	21
CAT5e/6/7	22
APPENDIX 1 Troubleshooting.....	23
APPENDIX 2 Firmware Update.....	24
DXM Update Utility & Hardware	24
APPENDIX 3 Technical Specifications.....	25
APPENDIX 4 Warranty	26

PACKAGE CONTENTS

Please make sure the following items are included within your package. Contact your dealer if any items are missing or damaged.

- DXM Card Cage (DXM-88, DXM-1616, DXM-3232 Accordingly)
- IEC Power Cord x 1
- Front Door Triangle Access Key
- Firmware updating cables (RJ-11 to inline)

		
Matrix Frame	User Manual	Front Door Triangle Access Key
		
Power cable	RS-232 Communication Cable	

Optional Accessories

Refer to Matrix Frames, Cards, Accessories section for full list of products available for the DXM G2 Series.

Note: Go to www.auroramultimedia.com for latest manual and firmware

INTRODUCTION

About

Aurora's 2nd generation Digital Xtreme Matrix (DXM) switchers now with HDBaseT CAT I/O cards offering 1080P 60Hz transmission over CAT cable up to 600ft. All units with auto EDID learning and management for ease of setup. Associated HDBaseT Tx and Rx modules are remotely powered by the DXM units over CAT cable. The new units also offer flexible RS232 signal routing to individual outputs or to all outputs simultaneously for unprecedented display control. With a full assortment of Input cards no format is left behind with crystal clear digital conversion to 1920 x 1080 60Hz.

Features

- ◆ Card Cage Sizes of 8x8, 16x16, 32x32
- ◆ Configurable as 4-channels per Card
- ◆ 12.8Mbps Bandwidth per Port
- ◆ Hot Pluggable Input and Output Cards
- ◆ Redundant Power Supply for 16x16 and 32x32
- ◆ EDID Management
- ◆ HDCP Compliant
- ◆ VGA Input / Output Cards
- ◆ 3G/HD/SD SDI Input / Output Cards
- ◆ HDMI Input / Output Cards (Output Cards w/Audio De-embedding & Auto DVI Detect)
- ◆ HDBaseT CAT Input / Output Cards (Powers remote Tx/Rx units & bi-directional RS-232)
- ◆ Fiber Input / Output Cards up to 6600 feet (2000m)
- ◆ YPbPr Input Cards
- ◆ Composite Input Cards
- ◆ Presets
- ◆ Front LCD status
- ◆ Front Panel Button Control
- ◆ RS-232 Control
- ◆ Ethernet Control

MATRIX FRAMES, CARDS, & ACCESSORIES

DIGITAL XTREME (GEN 2) – FRAMES & CARDS	
<i>Matrix Card Frames</i>	
DXM-88-G2	8x8 Digital Xtreme Matrix Card Cage
DXM-1616-G2	16x16 Digital Xtreme Matrix Card Cage
DXM-3232-G2	32x32 Digital Xtreme Matrix Card Cage
<i>Input Cards</i>	
DXCI-4-HDMI-G2	4 Input HDMI Card
DXCI-4-HDBT1-G2	4 Input HDMI HDBaseT 230' CAT Card
DXCI-4-HDBT2-G2	4 Input HDMI HDBaseT 330'/600' CAT Card
DXCI-4-DVI-G2	4 Input DVI HDCP & Auto Eq for 30m Cable Support Card
DXCI-4-FIBR3-G2	4 Input Dual Multi-mode (300m) / Single-mode (2km) Fiber Card
DXCI-4-VGA-G2	4 Input VGA with Audio Card No Scaling
DXCI-4-2V2H-G2	4 Input 2 VGA with Audio & 2 HDMI Card
DXCI-4-SDI-G2	4 Input 3G/HD/SD/SDI Card
<i>Output Cards</i>	
DXCO-4-HDMI-G2	4 Output HDMI with audio de-embedder Card
DXCO-4-HDBT1-G2	4 Output HDMI HDBaseT 230' CAT Card
DXCO-4-HDBT2-G2	4 Output HDMI HDBaseT 330'/600' CAT Card
DXCO-4-DVI-G2	4 Output DVI / HDCP Card
DXCO-4-FIBR3-G2	4 Output Dual Multi-mode (300m) / Single-mode (2km) Fiber Card
DXCO-4-VGA-G2	4 Output VGA Card
DXCO-4-2V2H-G2	4 Output 2 VGA with Audio & 2 HDMI Card
DXCO-4-SDI-G2	4 Output 3G/HD/SD/SDI Card
<i>Redundant Power</i>	
DXM-PWR-G2	DXM Power Supply for 16x16 and 32x32



DXCI-4-HDMI-G2



**DXCI-4-HDBT1-G2 /
DXCI-4-HDBT1-G2**




DXCI-4-VGA-G2



DXCI-4-2V2H-G2



DXCO-4-HDMI-G2



**DXCO-4-HDBT1-G2 /
DXCO-4-HDBT-2-G2**

DIGITAL XTREME ACCESSORIES	
<i>External HDBT / Fiber Boxes and Wall Plates</i>	
DXE-CAT-RX1	230' HDBaseT Receiver (No PS)
DXE-CAT-RX2	330'/600' HDBaseT Receiver (No PS)
DXE-CAT-TX1	230' HDBaseT Transmitter (No PS)
DXE-CAT-TX2	330'/600' HDBaseT Transmitter (No PS)
DXW-2	2 Input HDBaseT Wall Plate (VGA & HDMI) - 230' CAT Extender
DXE-FIBR-TX3	HDMI to Dual Multi-mode (300m) / Single-mode (2km) Fiber Transmitter
DXE-FIBR-RX3	Dual Multi-mode (300m) / Single-mode (2km) Fiber Receiver to HDMI
<i>Rack Mounts / Power Supplies / Cables</i>	
DXE-CAT-RK3	3RU Rack Mount Kit for DXE-CAT-S1/S2/S2L (Fits up to 16 DXE-CAT units in 3RU space)
DXE-CAT-RK3BL	Blank Panels for DXE-CAT-RK3 Rack Mount
PS0053-1	24VDC PS w/US Adaptor (DXE-CAT)
CA0052-F2T3R	3.5mm TRS to FEMALE DB9 2-TX 3-RX (Null Modem)
CA0052-F3T2R	3.5mm TRS to FEMALE DB9 3-TX 2-RX
CA0052-M2T3R	3.5mm TRS to MALE DB9 2-TX 3-RX (Null Modem)
CA0052-M3T2R	3.5mm TRS to MALE DB9 3-TX 2-RX

DESCRIPTION

Front Panel DXM G2 Series



LCD	Backlit display for the status and operation
0-9	Input / Output port selection number keys.
Switch	The HDMI signal toggle selection key. Example: 3→ Switch→6→END→ENTER to switch signal from the input 3 to output 6.
&	Space key which is used to switch to many output ports at once. Example: 1→Switch→2→ & →3→ & →6→END→ENTER to switch signal from the input 1 to outputs 2, 3, 6 at the same time.
All	All command sends an input to every output at once or all inputs to each output on a one to one. Example: 7→ALL means switching signal from input 7 to the all output ports. Example: ALL→1 means all input ports to the all output one to one so that input 1 to output 1, input 2 to output 2 and so on. Example: ALL→2 means turn off all I/O channels.
Save	The save key saves the I/O configuration into a memory preset Example: SAVE→2 saves all I/O status into the NO.2 memory cell. "0 ~ 9" ten presets in all.
Recall	The recall key will restore a saved memory preset. Example: RECALL→2 restore the I/O status from the NO.2 memory preset.
Status	The status shows the matchup of inputs to outputs.
Cancel	The cancel key returns the DXM back to standby mode Example: 1→Switch→2→END→CANCEL clears the input order and user can type the new one if required.
END	The end key finishes a selection order.
ENTER	The enter key confirms a process selection.

Rear Panel DXM G2 Series



DXM-88-G2



DXM-1616-G2



DXM-3232-G2

IEC Power Connector(s)	110 / 220 power connector. DXM-1616 / DXM-3232 have 2 for redundant power. The lower power connector is the primary when a single supply is installed.
Fan Card	The card with the silver handle is for the fans.
Input Cards	The model will determine the amount of input cards. There are 4 ports per input card. The 8x8 has 2, 16x16 has 4, and the 32 x 32 has 8. Note the silk screen in the corner to match the cards in the correct slot type. Cards are hot swappable.
Output Cards	The model will determine the amount of output cards. There are 4 ports per output card. The 8x8 has 2, 16x16 has 4, and the 32 x 32 has 8. Note the silk screen in the corner to match the cards in the correct slot type. Cards are hot swappable.
LAN	Future Use. At this time if LAN operation is required it is recommend to use the Nugget Serial on the RS-232 port.
RS-232	Main Control Port. Refer to the Serial Command section for available commands. Recommended baud rate is 115k 8N1

OPERATION

Front Panel Menu Settings

Main Menu:

1. EDID Setting
2. RS232 Setting
3. Language
4. Beep Setting
5. Keypad Light
6. LCD Backlight
7. System Reset
8. Back

Sub Menu:

EDID Setting

1. EDID Update → 1/ External EDID
2/ Default EDID
3/ Back
2. EDID Manage → 1/ Save EDID
2/ Delete EDID
3/ Back
3. EDID Info
4. Back

RS232 Setting

1. Main PCB → 1/ Baud Rate
2/ Data bits
3/ Stop bit
4/ Parity
5/ Back
2. Input 1-16
3. Output 1-16
4. Back

Language

1. English
2. Back

Beep Setting

1. Turn on
2. Turn off
3. Back

Keypad Light

1. Turn on
2. Turn off
3. Back

LCD Backlight

1. Always on
2. 20 minutes
3. 15 minutes
4. 10 minutes
5. 5 minutes
6. Back

Switching with Front Panel

Note: Please use the following sequence for proper results.

- 1) Connect the source(s) output to the input(s) of the appropriate card
- 2) Connect the output(s) of this appropriate card to the destination(s) (ex. Display) input
- 3) Connect power cable and switch unit on. The indicator light will then light as well as the front LCD.
- 4) Finally, turn on the resource and display devices.
- 5) Use front panel to select the I/O port.
 - Press the number key for required input channel
 - Press the "Switch"
 - Press the number key for required output channel
 - Press the "END"
 - Press the "ENTER" at last

Example: Input 2 to Output 5 - 2→ Switch→5→END→ENTER"

Examples of operation

Example: To switch signal from the input 1 to Output 3 and 4 at the same time.

Input Command: 1-	1. press the input "1"
Input Command: 1X-	2. press the "switch"
Input Command: 1X3-	3. press the output "3"
Input Command: 1X3&-	4. press the "&"
Input Command: 1X3&4-	5. press the output "4"
Input Command: 1X3&4. -	6. press the "end"
Switch ok HDMI 01~004	7. press the "enter"

EDID Management

1) - Copy EDID from an output to one or multiple inputs:

Menu → EDID Settings → EDID Update → External EDID.

Command format:

[Output#] → Switch → [Input#] → End → Enter

Example:

2 → Switch → 1 → End → Enter: copy EDID from output 2 to input 1.

2 → Switch → 1&2&3 → End → Enter: copy EDID from output 2 to inputs 1, 2 and 3.

2) – Save EDID profile:

Menu → EDID Settings → EDID Manage → Save EDID

Command format:

[Output#] → Switch → [Profile#] → End → Enter

Example:

2 → Switch → 1 → End → Enter: save EDID from output 2 to profile #1.

3) – Load/Use saved EDID profiles for one or multiple inputs:

Menu → EDID Settings → EDID Update → Default EDID → Select an EDID profile.

Command Format:

[Input#] → End → Enter

Example:


Profile 2 is selected.

1&2 → End → Enter: EDID profile #2 is sent to input 1 and 2.


CARD FUNCTIONALITY

HDBaseT Cards

HDBaseT input and output cards are designed to receive or transmit audio, video, control, and power up to 600ft with 24bit 1080p 60Hz depending on model using a single common CAT 5e / 6 / 6A cable. DXCI-4-HDBT1 & DXCO-4-HDBT1 will go up to 230ft with 36bit color depth. DXCI-4-HDBT2 & DXCO-4-HDBT2 will go up to 330ft 48 bit color depth or 600ft with 24bit color depth (CAT 6A shielded cable required for this distance). The output card has the unique ability to auto detect a DVI display or device connected and automatically remove the audio from the signal even if the source is HDMI. This saves space and cost as an external device to strip the audio electrically is not required. The need to learn a DVI EDID is not required with the DXM series due to this feature.



DXCI-4-HDBT1-G2 / DXCI-4-HDBT2-G2



DXCO-4-HDBT1-G2 / DXCO-4-HDBT2-G2


LED	Description
W	HDBT port microprocessor is working properly when flashing
D	HDCP Status LED will be solid when HDCP is present or flash when there is none.
C	Connectivity LED should be solid with a proper cable link to HDBaseT transmitter or receiver accordingly.
V	Video Signal LED should be solid when video is present

HDMI Cards

HDMI input and output cards support 1080p 60Hz video resolutions with stereo and Dolby® Surround Sound audio. The input and output cards will work with DVI signals. The output card has the unique ability to auto detect a DVI display or device connected and automatically remove the audio from the signal even if the source is HDMI. This saves space and cost as an external device to strip the audio electrically is not required. The need to learn a DVI EDID is not required with the DXM series due to this feature. The output card also has the ability to audio de-embed and allow stereo output via the 3.5mm TRS connector.



DXCI-4-HDMI-G2 / DXCI-4-HDMI-G2



DXCO-4-HDMI-G2 / DXCO-4-HDMI-G2

LED	Description
V	Video Status LED will light solid when video signal is present.
A	Audio Status LED will light solid if audio is present. (Output Card only)

SERIAL COMMANDS

RS-232 Commands

NOTES:

! IS A COMMAND (Case sensitive)

? IS A QUERY COMMAND (Case sensitive)

~ IS A RESPONSE (All responses are in the same case as the command)

"<CR>" Represents a carriage return (Hexadecimal character 0x0D or Decimal 13")

Timing between commands – Wait at least 250ms between commands (version 2.1.8 and above)

Command	String Format	Information
Route Command	!Rxtoz<cr>	x = input port number = 0-32 (0 is to unroute) z = output port number(s) = 1-32 For more than one port number use a comma to separate. Example 1,4,5
Preset Command	!Px<cr>	x = 1-9
Preset Save Command	!Sx<cr>	x = 1-9
Baud Rate Setup Input Command	!BRabINx<cr>	a = baud rate = 2400, 4800, 9600, 19200, 38400 b = bits, parity, stop = 8N1, 8E1, 8O1 x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between.
Baud Rate Setup Output Command	!BRabOUTx<cr>	a = baud rate = 2400, 4800, 9600, 19200, 38400 b = bits, parity, stop = 8N1, 8E1, 8O1 x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between.
Serial Input Card Port Receive	!RXaINx<cr>	a = OFF or ON x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between. Note: To limit traffic on main RS-232 port turn off ports where the feedback does not matter.
Serial Output Card Port Receive	!RXaOUTx<cr>	a = OFF or ON x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between. Note: To limit traffic on main RS-232 port turn off ports where the feedback does not matter.

Serial Transmit Input Command	!RSINxTXnns<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between nn = byte count for string = 00 - 99 Number must be double digit and in ASCII. Single digits must have zero in front s = string is in ascii and can have non-printable ascii characters as well. Refer to the control system manual how to send hexadecimal inside a string. Note the hexadecimal counts as only 1 byte for the byte count. Aurora control system uses URL encoded methods for sending strings so "hello world <cr>" would be hello world%0D. This would have 12 bytes for the byte count as %0D counts as one byte. Some systems may use 0x0D instead.
Serial Transmit Output Command	!RSOUTxTXnns<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between nn = byte count for string = 00 - 99 Number must be double digit and in ASCII. Single digits must have zero in front s = string is in ascii and can have non-printable ascii characters as well. Refer to the control system manual how to send hexadecimal inside a string. Note the hexadecimal counts as only 1 byte for the byte count. Aurora control system uses URL encoded methods for sending strings so "hello world <cr>" would be hello world%0D. This would have 12 bytes for the byte count as %0D counts as one byte. Some systems may use 0x0D instead.
DVI Output Mode Force On	!DVIONx<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
DVI Output Mode Auto	!DVIOFFx<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Hot plug Output Auto	!HPONx<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Hot plug Output force off	!HPOFFx<CR>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Query Input Card Baud Rate	?BRINx<cr>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Query Output Card Baud Rate	?BROUTx<cr>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Query Input Card Serial Receive	?RXINx<cr>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Query Output Card Serial Receive	?RXOUTx<cr>	x = port number(s) = 1-32 1-32 1-32 etc. More than one port # use space between
Query Firmware Input Port (only for RS-232)	?FMINPx<cr>	x = port number = 1-32 Note: Command only works for HDBaseT cards.

ports)		
Query Firmware Input Card	?FMINCx<cr>	x = port number = 1-8
Query Firmware Output Port (only for RS-232 ports)	?FMOUTPx<cr>	x = port number = 1-32 Note: Command only works for HDBaseT cards.
Query Firmware Output Card	?FMOUTCx<cr>	x = port number = 1-8
Query Firmware Main Processor	?FM0<cr>	Zero is default for main processor firmware query
Query Input Route	?Rx<cr>	x = port number = 1-32 Note if input is routed to more than one output then multiple port numbers will be listed in response separated by a space.

Note: Firmware query commands do not work on analog cards.

RS-232 Command Usage

Example	Example String	Example Response
Route Input 5 to Output 1, 2, 3, and 4	!R5to1,2,3,4<cr>	~R5to1,2,3,4<cr>
Trigger Preset 2	!P2<cr>	~P2<cr>
Save current configuration into Preset 5	!S5<cr>	~S5<cr>
Set Input Port 1 Baud Rate to 96008N1	!BR96008N1IN1<cr>	~BR96008N1IN1<cr>
Set Output Ports 1, 3, 5, and 13 Baud Rate to 192008N1	!BR192008N1OUT1 3 5 13<cr>	~BR192008N1OUT1 3 5 13<cr>
Turn off input ports 11 & 15 auto receive	!RXOFFIN11 15<cr>	~RXOFFIN11 15<cr>
Turn on output ports 11 & 15 auto receive	!RXONOUT11 15<cr>	~RXONOUT11 15<cr>
Send ASCII Serial string "123<CR>" to Input ports 1, 3, and 12. Note the %0D in an Aurora control system is Hexadecimal 0x0D and counts as 1 byte.	!RSIN1 3 12TX04123%0D<CR>	~RSIN1 3 12TX04123%0D<CR>
Send ASCII Serial string "123<CR>" to output ports 1, 3, and 12. Note the %0D in an Aurora control system is Hexadecimal 0x0D and counts as 1 byte.	!RSOUT1 3 12TX04123%0D<CR>	~RSOUT1 3 12TX04123%0D<CR>
Force HDMI output card to DVI mode on outputs 1-7	!DVION1 2 3 4 5 6 7<CR>	~DVION1 2 3 4 5 6 7<CR>
Query Baud Rate on Inputs 1, 12, & 13. Response shows input 1 38400 8N1; input 12 19200 8N1; input 13 4800 8N1;	?BRIN1 12 13<cr>	~BR384008N1IN1<cr> ~BR192008N1IN12<cr> ~BR48008N1IN13<cr>
Query Baud Rate on Output 4, 7, & 8. Response is output 4 9600 8N1; output 7 19200 8N1; output 8 38400 8n1;	?BROUT4 7 8<cr>	~BR96008N1OUT4<cr> ~BR192008N1OUT7<cr> ~BR384008N1OUT8<cr>

Query Input Port 1, 3, & 5 Serial Receive	?RXIN1 3 5<cr>	~RXIN1ON <cr> ~RXIN3ON <cr> ~RXIN5OFF<cr>
Query Output Port 1 Serial Receive	?RXOUT1<cr>	~RXOUT1ON<cr>
Query Input Port 1 Firmware	?FMINP1<cr>	~FMIN1-2.0.0<cr>
Query Input Card 1 Firmware	?FMINPC1<cr>	~FMINC1-2.0.0<cr>
Query Output Port 1 Firmware	?FMOUTP1<cr>	~FMOUT1-2.0.0<cr>
Query Output Card 1 Firmware	?FMOUTC1<cr>	~FMOUTC1-2.0.0<cr>
Query Main Processor firmware	?FM0<cr>	~FM0-2.0.0<cr>
Query Input 13 Route. Response shows it is routed to 2, 9, & 26	?R13<cr>	~R13to2,9,26<cr>

DXW-2 Series Wall Plate RS-232 Reporting Examples

Example	DXW Command	DXM Command
Button 1 pressed on DXW2	~BP1<cr>	~RSIN1TX05~BP1<cr><cr>
Button 2 pressed on DXW2	~BP2<cr>	~RSIN1TX05~BP2<cr><cr>

Example from DXW via DXM:

~RSIN1TX05~BP1<cr><cr>


“~RSIN1”: Signifies input 1 on matrix.

“TX05”: Is the byte count of the DXW string being sent of 5 (“~BP1<cr>”)

CONNECTOR PIN DEFINITION


RS-232 Serial Port

Baud Rate: Selectable by front panel.



NO.	PIN	STATE
1	N/A	
2	Tx	TX
3	Rx	RX
4	N/A	
5	GND	GND
6	N/A	
7	N/A	
8	N/A	
9	N/A	

HDMI












Type A (Receptacle) HDMI

Pin 1	TMDS Data2+	Pin 8	TMDS Data0 Shield	Pin 15	SCL
Pin 2	TMDS Data2 Shield	Pin 9	TMDS Data0–	Pin 16	SDA
Pin 3	TMDS Data2–	Pin 10	TMDS Clock+	Pin 17	DDC/CEC Ground
Pin 4	TMDS Data1+	Pin 11	TMDS Clock Shield	Pin 18	+5 V Power
Pin 5	TMDS Data1 Shield	Pin 12	TMDS Clock–	Pin 19	Hot Plug Detect
Pin 6	TMDS Data1–	Pin 13	CEC		
Pin 7	TMDS Data0+	Pin 14	Reserved (N.C. on device)		

CAT5e/6/7

T568A and T568B Wiring

Pin	T568A Pair	T568B Pair	Wire	T568A Color	T568B Color	Pins on plug face (socket is reversed)
1	3	2	tip	 white/green stripe	 white/orange stripe	 Pin Position 8 7 6 5 4 3 2 1
2	3	2	ring	 green solid	 orange solid	
3	2	3	tip	 white/orange stripe	 white/green stripe	
4	1	1	ring	 blue solid	 blue solid	
5	1	1	tip	 white/blue stripe	 white/blue stripe	
6	2	3	ring	 orange solid	 green solid	
7	4	4	tip	 white/brown stripe	 white/brown stripe	
8	4	4	ring	 brown solid	 brown solid	

APPENDIX 1 Troubleshooting

For best results always make certain you have the latest firmware.

Problem	Solution
1. No Video Signal.	a. Check that the power plug is properly inserted into a functioning power outlet. b. Make certain source is on. c. Verify pin-out of connector at each end. d. If used in electrical noisy environment shielded CAT cable may be required. e. Verifying routing is correct
2. LED is not lit	a. Check to see if Wall supply is plugged into wall outlet. b. Make certain wall outlet has power.
3. No Dolby® Surround Sound	a. Make Certain the proper EDID from a Dolby® capable receiver unit is learned. Note this could affect non-Dolby® devices from playing sound if the source outputs Dolby®.
4. LEDs on HDBaseT cards alternating	a. Pull out all cards and reseal each card one by one until defective card is found. The pattern signifies the backplane bus cannot communicate and something is tying the bus up.
5. RS-232 commands not working	a. If you are using HyperTerminal to test try to use Hercules as it can send the commands in one shot vs. typing it in. The speed at which the commands are sent could affect operation.

1. All transmission distances are measured using Belden 1583A CAT5e 125MHz Solid UTP cable. The transmission distance is defined as the distance between the video source and the display.
2. To reduce the interference among the unshielded twisted pairs of wires in UTP cable, you can use shielded STP cables to improve EMI problems, which is worsen in long transmission.

Warning: Do not plug RJ-45 HDBaseT output to non-HDBaseT complaint devices or damage may occur to either product.

APPENDIX 2 Firmware Update

DXM Update Utility & Hardware

DXM Update Software requires the DXM-PGM1 device. Refer to the DXM-PGM1 manual for more information.

APPENDIX 3 Technical Specifications

Model Name	DXM Series Card Cage
Technical	
RS-232 Baud Rate	Max 115kbps
LAN Speed	1 - 10/100
LAN Connectors	8P8C RJ-45
RS-232 Connector	DB-9 Female
Power Connector	IEC
Mechanical	
Housing	Black Aluminum enclosure
Dimensions	3 RU – DXM-88 7 RU – DXM-1616 8 RU – DXM-3232
Mounting	19" Rack Mounting
Power supply	110/220
Operation temperature	0~40°C [32~104°F]
Storage temperature	-20~60°C [-4~140°F]
Relative humidity	20~90% RH [no condensation]

Specifications subject to change without notice.

APPENDIX 4 Warranty

Limited 3 Year Warranty

Aurora Multimedia Corp. ("Manufacturer") warrants that this product is free of defects in both materials and workmanship for a period of 3 years as defined herein for parts and labor from date of purchase. This Limited Warranty covers products purchased in the year of 2009 and after. Motorized mechanical parts (Hard Drives, DVD, etc), mechanical parts (buttons, doors, etc), remotes and cables are covered for a period of 1 year. Touch screen displays are covered for 1 year; touch screen overlay components are covered for 90 days. Supplied batteries are not covered by this warranty. During the warranty period, and upon proof of purchase, the product will be repaired or replaced (with same or similar model) at our option without charge for parts or labor for the specified product lifetime warranty period.

This warranty shall not apply if any of the following:

- A. The product has been damaged by negligence, accident, lightning, water, act-of-God or mishandling; or,
- B. The product has not been operated in accordance with procedures specified in operating instructions; or,
- C. The product has been repaired and or altered by other than manufacturer or authorized service center; or,
- D. The product's original serial number has been modified or removed; or,
- E. External equipment other than supplied by manufacturer, in determination of manufacturer, shall have affected the performance, safety or reliability of the product.
- F. Part(s) are no longer available for product.

In the event that the product needs repair or replacement during the specified warranty period, product should be shipped back to Manufacturer at Purchaser's expense. Repaired or replaced product shall be returned to Purchaser by standard shipping methods at Manufacturer's discretion. Express shipping will be at the expense of the Purchaser. If Purchaser resides outside the contiguous US, return shipping shall be at Purchaser's expense.

No other warranty, express or implied other than Manufacturer's shall apply.

Manufacturer does not assume any responsibility for consequential damages, expenses or loss of revenue or property, inconvenience or interruption in operation experienced by the customer due to a malfunction of the purchased equipment. No warranty service performed on any product shall extend the applicable warranty period. This warranty does not cover damage to the equipment during shipping and Manufacturer assumes no responsibility for such damage.

www.auroramultimedia.com

Aurora Multimedia Corp.

205 Commercial Court

Morganville, NJ 07751

Phone: 732-591-5800 Fax: 732-591-6801